

Providència, 70 08024 - Barcelona Tel.: (+34) 932 857 040 Fax: (+34) 932 841 109 www.josemestre.com

MANUAL DISPENSER MACHINE

GENERAL DESCIPTION OF THE PRODUCT:

This device is delivered completely prepared for being installed. It is composed of a hopper and four types of nozzle, which are produced in stainless steel.

USE:

To package gels and creams.

MAXIMUM DOSAGE PER PUSH:

Between 20 and 30 ml.

INSTRUCTIONS FOR USE:

- Place the appropriate nozzle for the job to be done.
- Deposit the gel or cream in the hopper.
- Make a few impulses until cream comes out of the nozzle.
- Adjust the amount of product using the wheel and guided by the numbering engraved on the piston rod.

MAINTENANCE:

- Once the work is finished, put hot water with neutral soap in the hopper and start the machine again. With this, the product that remains inside the machine is expelled.
- Disassemble the machine and proceed to clean it.
- Dry and proceed to assembly again.

ROSER HUARTE PRATS Technical Director Biologist bar assn. No. 14413-C

REVISION DATE: 14/09/2023